

# BTIR-2: Pre Launch Checklist

Notes	Activity
	Weigh PM-19 & BTIR-2 + Pictures
	Check BTIR-2 & PM-19 for visual defects
30 meters from viewing location	Position LaunchPad
Do not arm	Position ICBM-B next to LaunchPad
Turn them off to save battery	Position camera's 1 Main near, 1 Backup near, 1 Backup far
Be careful not to snag it	Roll out ICBM extension cable to max length, and setup viewing location there
	Position ICBM-A at viewing location, and connect to ICBM-B
Test SAS from viewing position	Place Safety Announcement System next to ICBM-B
Make sure PM-19 is stowed	Test system with igniter (type II, LQ)
Check continuity first	Insert shorted Igniter (type II, HQ) into PM-19
	Insert PM-19 into BTIR-2 Core Stage
	Disarm systems and place BTIR-2 onto LaunchPad
	Start camera's, and double check they are recording and have enough charge and storage
All parties need to give "Go"	"Go, No Go" Call
	ARM ICBM-B and confirm continuity, Reach safe distace and ARM ICBM-A
Good luck and Godspeed	Countdown + Launch
	Move on to BTIR-2 Checkout CheckList